1.1 INTRODUCTION

The 960 Micro Sweep series consist of four compact, lightweight microwave sweep generators that collectively cover the 1 to 18 GHz frequency range. These generators feature three operating modes (Start/Stop Sweep, ΔF Sweep, and CW) with three independently settable frequency markers. Frequency is displayed to 10 MHz resolution on a LCD display.

Frequency can be swept using either of two sweep modes (Start/Stop Sweep and ΔF Sweep). In Start/Stop Sweep, both the start and stop frequencies can be independently set; the Micro Sweep may be swept up or down in frequency. In ΔF Sweep, the center frequency and total frequency deviation each can be controlled; ΔF Sweep sweeps symmetrically upward only. For both sweep modes, the maximum sweep width is 100% of a Micro Sweep's frequency band, while the minimum sweep width is approximately 1%. Both sweep can be auto-triggered (continuous sweep) or triggered which allows the sweep to be started by an external signal. Furthermore, the frequency can be remotely controlled (External Tune) or frequency modulated (FM).

Three independently settable frequency markers can be used in the two sweep modes, CW, and external frequency tuning. These markers may be RF PIP, Z-Axis, or both. Internal switches select the type of marker. Plus, the polarity of the Z-Axis (Intensity markers) output can be set, using internal switches, for either positive or negative intensity control of an oscilloscope trace. In addition, marker intensity or PIP depth also can be set.

Output power is continuously variable. Maximum power is greater than ± 12 dBm, unleveled, or ± 10 dBm internally leveled. RF level control range is greater than 25 dB, unleveled, and a nominal 7dB when leveled. An optional internal leveler (Option 001) maintains the output level within ± 1.0 dBm or better across the Micro Sweep's frequency band. The RF output also may be leveled using an external coupler and diode detector. The output can be amplitude modulated (AM) using an external signal.

1.2 SPECIFICATIONS

1.2.1 Frequency Characteristics

Frequency Range

The frequency ranges of the Model 960 Series Micro Sweeps are as follows:

Model 962	1.0 — 4.0 GHz
Model 964	3.7 — 8.4 GHz
Model 965	7.0 — 12.4 GHz
Model 967	12.0 — 18.0 GHz

Frequency Accuracy

When operated at 25°C \pm 10% and maximum RF output, the absolute frequency accuracy of the Model 960 Series Micro Sweep is better than \pm 1% (0.5% typical) for CW, \pm 1% (typical) for Markers and Center Frequency, and \pm 2% (typical) for Start, Stop, and Δ F.

Display Resolution

The front panel display resolution is 10 MHz.

Frequency Stability

With Temperature

With Load (midband

3:1 VSWR)

The frequency stability (typical) of the Model 960 Series is measured after 1 hour warm-up in a constant environment. Other conditions apply as indicated.

0.007% per °C (0 to

+ 50°C).			
0.001% with 10% line voltage change.			
0.004% over 5 minutes (after 1 hr. warm up and 15 minutes following any frequency change).			
0.01% over 1 hr. (after 1 hr. warm up and 15 min. following any frequency change).			

0.1%.

Spectral Purity

	Model					
	962	964	965	967		
Residual FM Peak (50 Hz to 15 kHz post- detection bandwidth)	8 kHz	15 kHz	20 kHz	25 kHz		
Spurious	- 55 dBc	- 55 dBc	- 55 dBc	- 55 dBc		
Harmonics (maximum)	- 12 dBc*	- 20 dBc	- 20 dBc	- 20 dBc		

^{*} For output levels less than - 10 dBm, the harmonic specification is - 10 dBc.

Frequency Control

Manual Tuning: A ten turn control knob sets the CW frequency, marker frequencies, and Center Frequency (CF in Δ F Swp). Two single turn control knobs set the Start, Stop, and Δ F frequencies.

External Tune: 0 to + 10V controls the Micro Sweep for the full tuning range; Swp Time control must be in the Ext Tune position for external frequency tuning.

1.2.2 Operating Modes

Start/Stop Sweep: Sweeps from the frequency set by the Start control to the frequency set by the Stop/ ΔF control. Both frequencies are continuously adjustable over full range. Pressing the front panel S/S Swp pushbutton selects the Start/Stop sweep mode. Pushbuttons below the LCD readout select the frequency displayed. Minimum practical sweep width is approximately 1% of band. Downward sweep is permitted but does not provide markers.

ΔF Sweep: Sweeps symmetrically upward, centered on the frequency (CF) set by the main tuning knob. Pressing front panel ΔF Swp pushbutton selects the ΔF sweep mode. Sweep width is set by using the Stop/ ΔF sweep control, and the center frequency is set with the main tuning knob. Pushbuttons below the LCD readout select the frequency displayed. Width is adjustable from 100% to less than 1% of the band. Sweeping beyond the frequency limits of the Micro Sweep is not permitted.

CW Operation: Single frequency RF output is controlled by the main tuning knob. Pressing front panel CW mode pushbutton selects the CW mode. An illuminated LED near the main tuning knob indicates when the knob is functioning as CW, Center Frequency, or marker frequency control.

1.2.3 Sweep Capability

Sweep Modes

The two sweep modes (Start/Stop and ΔF Swp) are described in paragraph 1.2.2.

Sweep Time

Continuously adjustable from 0.02 to 20 seconds, nominal, per sweep.

Sweep Out/Ext Tune in

Internal Sweep

Sweep output is 0 to +10V directcoupled, modified sawtooth waveform regardless of sweep width.

CW

Sweep output is linearly proportional to frequency with 0V (lowest frequency) to +10V (highest frequency), nominal, for full Micro Sweep bandwidth.

Frequency Markers

Three constant width markers, independently adjustable over the full frequency band of the Micro Sweep, are available for all sweep functions (Start/Stop, ΔF , and Remote) plus CW. Markers are only produced when the frequency is swept from low to high frequency.

Intensity Marker: A rectangular pulse provides a marker signal for the Z-axis input to oscilloscope. Pulse polarity is factory set for a negative-going pulse, but may be changed to a positive-going pulse via an internal switch (see paragraph 2.2.3 and figure 3-4). Retrace blanking signal will be of the opposite polarity. A front panel trim adjustment permits intensity adjustment.

Amplitude (RF PIP) Marker: The RF PIP marker is generated by momentarily reducing the RF output. (Factory set position enables this type of marker.) The RF PIP maker can be disabled with an internal switch (see paragraph 2.2.3). A front panel trim adjustment permits PIP depth adjustment.

Operation: Marker 1, Marker 2, and Marker 3 are set in any order by first pressing the pushbutton of the desired marker and displaying its frequency on the LCD readout; this activates the marker to accept other commands. The marker being displayed and operated on is identified by a flashing indicator. Markers which are off will blink with a short duty cycle, and markers which are on will blink with a long duty cycle. The marker is then toggled on or off using the On/Off pushbutton. The marker frequency is changed by pressing the Update pushbutton to "on" and then adjusting the main turning knob.

Resolution: Each marker may be set to a digitized resolution of 0.1% of the Micro Sweeps bandwidth. Display resolution is 10 MHz.

Blanking

During retrace, a +5V, nominal, direct coupled rectangular pulse provides the Z-axis input to the oscilloscope. Polarity may be changed to negative by changing an internal switch (see paragraph 2.2.4 and figure 3-4). RF blanking is not provided.

Sweep Trigger

Auto-Trigger: Sweep is automatically triggered on a continuous basis.

External Trigger: A single sweep is triggered by a signal at the front panel Trig In BNC. Pressing the Ext Trig pushbutton selects this mode as indicated by an illuminated Ext Trig pushbutton. The sweep is triggered by the falling edge (high or low) of a TTL signal or a switch contact closure to ground. A double press of the pushbutton

will manually trigger a single sweep at slower sweep rates; there will be a brief delay before the sweep begins.

1.2.4 External Modulation

AM

Depth 0 to 25 dB min. (30 dB typical) for a 0 to +10V input.

Bandwidth 50 kHz typical 3dB bandwidth, dc coupled.

Input $10 \text{ k}\Omega$ nominal.

Impedance

FΜ

Deviation $\pm 5MHz$ min. deviation for $\pm 4V$

Inpu Bandwidth 50 k

50 kHz typical, 3dB bandwidth, dc

coupled.

Input Impedance 10kΩ nominal.

1.2.5 Output Characteristics

(See table 1-1.)

Table 1-1. Output Characteristics

1 CONTROL OF					
		Model			
	962	964	965	967	
Output Power Unleveled (without internal leveling option 001)	+ 12 dBm	+ 12 dBm	+ 12 dBm	+ 12 dBm	
Leveled (via internal leveling option 001)	+ 10 dBm	+ 10 dBm	+ 10 dBm	+ 10 dBm	
Unleveled (with internal leveling option 001 installed	+ 11 dBm	+11 dBm	+11 dBm	+ 11 dBm	
RF Level Control Range Unleveled Operation Leveled Operation		25 dB minimum, 30 dB typical. 7 dB nominal.			
RF Leveling Internal Option		Flat ±1.0 dE	3, maximum.		
External Leveling (at maximum output using HP 8472A negative polarity detector and 16 dB coupler)		Flat ±0.1 dB maximum, excluding coupler/detector variations.			
Input Sensitivity		 50 dB/mV nominal, gain adjustment provided at front panel. 			
Input Impedance		1kΩ nominal.	•		
Output Impedance		50Ωnominal.			
VSWR (with internal leveling option)	<2.5	<1.5	<1.5	<1.5	

1.2.6 General

Connectors

RF Output:

Precision Type N. CEE22 Type VI.

AC Power: All Others:

BNC.

Environment

Operating

Temperature:

0 to +50°C.

Nonoperating

Temperature:

- 40 to + 75°C (Rate of temperature change not to exceed 1° per minute).

Humidity:

0 to 95% noncondensing.

Dimension:

21.6 cm (8½ in.) wide; 9.8 cm (3½

in.) high; 29.9 cm (11 3/4 in.) deep.

Weight: Power:

5.4 kg (12 lb), nominal.

90 - 126V or 198 - 252V; 50 - 400

Hz; 40 VA.

1.2.7 Storage

Short Term (<30 days): Same as Environmental limits; see 1.2.6 General.

Long Term (>30 days): Refer to Preparation for Shipment; see 1.2.6 General.

1.2.8 Options

001 Internal Leveling

1.3 ITEMS FURNISHED

Each Micro Sweep is shipped with an instruction manual and a power cable.

1.4 ITEMS REQUIRED BUT NOT FURNISHED

 50Ω BNC and 50Ω Type N coaxial cables are required to interconnect the Micro Sweep to other devices during operation. Items referenced in table 1-2 are required to perform maintenance on the Micro Sweep.

1.5 TEST EQUIPMENT

The tools and test equipment required to perform the checkout procedure, troubleshooting, and calibration procedures are contained in table 1-2.